

Contents

- [1 Introduction](#)
- [2 Preparation](#)
- [3 Broadcom](#)
[Considerations](#)
- [4 Atheros](#)
[Considerations](#)
- [5 Repeater Setup](#)
 - ◆ [5.1 Testing](#)
 - ◆ [5.2](#)
[Footnotes](#)
- [6](#)
[Tips/Gotcha's/Problems](#)
- [7 See also](#)

Introduction

If you got here from Google you may wish to read [Linking Routers](#) first. In fact, no matter how you got here, you should look at that page first.

This mode is NOT for WIRED connections between two routers! It is a wireless connection only.

- No setup changes are required to be made to your host-router / AP except that you usually must use WPA2-AES ONLY for dd-wrt to work. Also, some other revisions or adjustments may be desirable, as stated below.
- if your host AP is 192.168.1.x, then your repeater could be subnet 192.168.2.x or 192.168.69.1 or ... any other unique subnet in your network. If you need a repeater-type solution in the same subnet you are in the wrong place. You need to read [Linking Routers](#) first..!

Preparation

You need to know the host router's access credentials:

- SSID
- the security settings
- its IP address
- prepare and verify the DD-WRT to be configured as a repeater
 - ◆ Note: **Make sure you are using a RECENT STABLE BUILD!!! DO NOT USE THE**

RECOMMENDED BUILDS ON THE DD-WRT HOMEPAGE, those are outdated and buggy. Where do I download firmware?

- ◆ cable-connect your repeater-to-be to a laptop or desktop
- ◆ install or upgrade the DD-WRT firmware (if required)
- ◆ do a 30 sec reset (see [Hard reset or 30/30/30](#)).
- ◆ verify which chip set your device uses and read Broadcom / Artheros considerations, below
- ◆ proceed with installation

Broadcom Considerations

Note: NEVER use v24 SP1. As mentioned above, check the forum stickies (such as the Peacock thread) for the latest recommended stable build.

Atheros Considerations

There is no "Repeater" mode on Atheros units, but you still can use it as repeater, just set the original interface as "client" and get it to connect to your AP, then create a virtual interface (VAP) to broadcast the new SSID.

Repeater Setup

1. Do a [hard reset](#)).
2. Under **Wireless -> Basic Settings**:
 - ◆ Wireless mode: Repeater
 - ◆ Wireless Network Mode: [set to match the host]
 - ◆ Wireless Network Name (SSID): [set to match the host]
 - ◆ Save
 - ◆ Add one virtual interface
 - ◆ Enter a new (unique) SSID of your choice
 - ◆ Save
3. Under **Wireless->Wireless Security**:
 - ◆ Physical Interface w10:
 - ◇ Enter the necessary settings to connect to the wlan you'd like to repeat (if no security, leave disabled...but consider enabling security for both host AP and Repeater)
 - ◇ Save
 - ◆ Virtual Interface w10.1:
 - ◇ Choose the best security mode, which should be WPA2-AES whenever possible. The only other mode that will usually work is wep, which is not secure. Other modes normally do not work with ddwrt. See the peacock announcement
 - ◇ Enter a security key
 - Note: When using security on both the physical and virtual interfaces, you must (usually) use the same security type, and exactly the same passphrase on both the physical and virtual ssid. If you cannot connect when trying different security or passphrases, make them identical.
 - ◇ Save
 - ◆ Note: If you experience problems when setting up for the first time, a leading practice is to configure without any encryption (i.e. setting security to "None") at first, until the unit is

Wlan_Repeater

confirmed to be working properly, and configuring encryption as a later step.

4. Under **Setup->Basic Setup**:

◆ Network Setup:

- ◇ Here you define the repeater's own subnet
- ◇ Set IP address to a different subnet from the Host AP you wish to repeat
- ◇ Example: if host AP is 192.168.1.x, assign repeater to 192.168.2.1
- ◇ Set up your DHCP range if you desire

◆ Save

5. (Optional but recommended) Under **Security**:

◆ Uncheck all items in the "Block WAN Request" section (except Filter Multicast)....THEN disable the SPI firewall

- ◇ Note: If you are very concerned about security, a Repeater might still work okay with the SPI firewall enabled. If you decide to leave it enabled but experience problems, keep this step in mind.

◆ Save

6. Recheck each tab and section to ensure that your settings are correct. Then click APPLY to write changes.

Testing

- After the Repeater has rebooted, disconnect power and let it cool a bit... (let ARP expire)
- Turn power back on and let it boot
- See if you can ping 192.168.1.x and access an outside website

Footnotes

Ensure the repeater is within radio range of your host network. When the unit has logged onto the Host WLAN and has begun repeating its signal, you will see the DHCP address (generally in the 192.168.1.100-200 range) in the upper right-hand corner as the WAN address. If it shows 0.0.0.0, it is not linked, and not repeating. Refresh (F5) the browser page to make sure the WAN IP is current, when making changes.

To access your secondary router from devices on your primary LAN, go to *Administration->Management->Remote Access* and enable *Web GUI Management*. You should then be able to access the secondary router by typing in its WAN IP. Setting up a static lease for the device in *Services/Services* will allow you to always know where it is to access it.

But for the pièce de résistance, enter the Host WLAN router's web GUI (*NAT/QoS->Port Forwarding* in DD-WRT) and set up a port forward so you can check on and fully access and control your new repeater outside the WAN (via the Internet). Check the DHCP IP address assigned to the new repeater (the *Host Name* entered in *Setup->Basic Setup->Optional Settings* will appear in the DHCP clients table of the Host router under *Status->Sys-Info*), and write it down. Then go to Port Forwarding and click "Add." Make the forwarded port (Port from) something you can remember easily, like 8128 if you found your repeater on 192.168.1.128, for example. Click Both for Protocol, enter the private IP address of the repeater in the IP Address box, enter Port 80 (http default) in the "Port to" box. Or if you want to be tricky, enter something besides 80, but just be sure this matches the active Web GUI port number on your repeater). Lastly, be sure to check "Enable," and then click "Save then "Apply". Then check the main WLAN router at its public IP address (or DDNS link) from outside the WAN, and also access the repeater GUI on the same address (or DDNS link) followed by :8128. E.g. <http://yourwlan.dyndns.org/> for your Host router and <http://yourwlan.dyndns.org:8128/> for the

repeater.

Tips/Gotcha's/Problems

- Note copied from Repeater Bridge mode, as it may also apply to Repeater mode: "Repeater Bridge with WPA2-AES is broken for k2.6 builds after 25974, though some models might work through 26125." See [Repeater Bridge](#) for original note.
- If you cannot get this to connect, first try disabling ALL wireless security to test. If that does not resolve your problems, try putting both the primary and secondary routers into "G only" mode.
- When MAC Address Cloning is enabled, the Wireless Security Mode of the repeated AP has to match that of the Virtual AP. So if the AP you wish to repeat has WEP encryption you need to use WEP for the Virtual AP. Without MAC Address Cloning, you may select any Wireless Security Mode for the Virtual AP, and it need not match the repeated AP.
- I have seen on some networks where Repeater mode will not provide a reliable connection if the STP function is Enabled on the Basic Setup page...Set it to Disabled and see if your connection improves.
- If the host AP settings *Wireless->Basic Settings->Wireless Network Mode* is "G-only", the repeater must also be set the same way. Otherwise it will fail the connection from the repeater side.
- Tests have shown that there is no way to lock a Repeater onto a particular channel.
- I was not able to get online with the Gateway and the Local DNS containing my router's IP as Stuckeymax suggested. Instead I left them as 0.0.0.0 and all was good.
- Also take note of the fact that all repeaters, including this Wlan Repeater mode, will sacrifice half of the bandwidth available from the primary router for clients *wirelessly* connected to the repeater. This is a result of the repeater taking turns talking to not just one partner, but to two, and having to relay the traffic between them. As long as your bandwidth requirements are within this halved bandwidth amount there will be little or no reduction in "speed". This is exactly the same as having two active wireless clients on one router.
- I tried a daisy chain of 4 routers AP-Rpt-Rpt-Clt, G-Only WPA2, all DHCP client from the previous, all managing it's own subnet with it's own DHCP-DNSMasq Authoritative (192.168.[1-2-3-4].0/24. Worked fine even with SPI firewall defaults enabled. No issues to manage all nodes from the net with the help of *Port Forwarding* and *Port Range Forwarding*.

See also

[Repeater Bridge](#)