

Fonera_Client_Bridged

(requires version 03/23/07 or greater for GUI setup)

Related documentation: [Wireless Bridge](#)

Forum thread: [0323 Client Bridge thread](#)

Setup > Basic Setup

WAN Connection: Disable

Network setup: Set fixed IP, subnet mask (ex.: 192.168.1.254, 255.255.255.0)

Network setup: Gateway and DNS: <equal to the other side> (ex.: 192.168.1.1, 192.168.1.1)

DHCP Server: Disable

Wireless > Basic Settings

Wireless Mode: Client Bridged

Wireless Network Mode: Mixed

Wireless > Wireless Security

<equal to the other side>

Security > Firewall

Disabled

Status > Wireless

Survey

(shows list of available networks. Select the proper one, then click Join and Close.)

PC:

Network setup: Set either DHCP or fixed IP:

Set IP and subnet mask (ex.: 192.168.1.253, 255.255.255.0)

Gateway and DNS: <equal to the other side> (ex.: 192.168.1.1, 192.168.1.1)