

only work for me if mode set to repeater bridge, not repeater

BrainSlayer

the standard repeater, must be configured to use a different subnet on ap side. a repater is nothing else than a client and a ap on one device. so the lan ip address must be configured to a different subnet as the client is using.

in repeater bridge this is not required for sure