

Contents

- [1 Ensure SSH Enabled](#)
- [2 Enable Remote Access](#)
- [3 Disabling Remote Access](#)
- [4 SSH Password](#)
- [5 References](#)

Ensure SSH Enabled

1. Goto the *Services* tab and the *Services* sub-tab on the [Web Interface](#)
2. Enable "SSHd" is under the section titled "Secure Shell"
3. 'SSH TCP Forwarding' does not need to be enabled if you just want to connect from the outside to your LAN.
4. Choose an appropriate port (The default is 22, but it is recommended that you change it to a non-standard port above 1024 for security reasons. Remember the port number, as you will need to enter it into your SSH client in order to connect to the router)
5. You can activate (less secure) password authorization and/or (recommended) private/public key authorization. More information about generating the keys can be found here: [\[\[1\]\]](#).
6. Save

Enable Remote Access

1. Goto the *Administration* tab and the *Management* sub-tab on the [Web Interface](#)
2. Enable "SSH Management" under the section titled "Remote Access"
3. Enter the same port number as specified under (4) above. This opens the port in the firewall.
4. Save
5. Reboot Router

Now you will be able to connect to your router's WAN IP from the internet using an SSH client such as [PuTTY](#).

Disabling Remote Access

If at any time you wish to disable SSH access from the WAN,

1. Goto the *Administration* tab and the *Management* sub-tab on the [Web Interface](#)
2. Disable "SSH Management" under the section titled "Remote Access"
3. Apply Settings

SSH Password

1. When asked for the **username**, enter **root** (even if you changed username in web interface)
2. When asked for the **password**, enter your router's password

References

- <http://hetos.de/sshtut.html>